

<b>CONVOYEURS</b>	<b>1515</b>	<b>1535</b>	<b>1545</b>	<b>1565</b>	<b>1575</b>	<b>1585</b>
Trémie basse (LP)		✓	✓			
Bâche de trémie	✓	✓	✓	✓	✓	✓
Moteur hydraulique	✓	✓	✓			
Kit PTO latéral				✓	✓	✓
Kit PTO en bout				✓	✓	✓